SONOFF

DIY Micro

Quick Installation Guide V 1.1

USB Smart Adapter

CN > EN > DE > ES > FR > IT > RU > PT

1

下载“易微联”APP
Download APP
APP herunterladen
Descargar la aplicación
Télécharger l'application
Scarica la APP
Скачать приложение
Baixe o app

eWeLink

Download on the App Store

GET IT ON Google Play

2

上 电
Power on
Einschalten
Encender
Allumer
Accensione
Включить
Ligue

通电后，设备首次使用，默认进入快速配网模式(Touch)。Wi-Fi指示灯呈“快闪状态”。

Powering on, the device will enter the quick pairing mode (Touch) during the first use. The Wi-Fi indicator flashes quickly.

Nach dem Einschalten wechselt das Gerät bei der ersten Inbetriebnahme in den Schnellkopplungsmodus (Touch). Die Wi-Fi-Anzeige blinkt schnell.

2

Después de encender, el dispositivo se pondrá en modo de emparejamiento rápido (Touch) durante el primer uso. El indicador de Wi-Fi parpadea rápidamente.

Après allumage, l'appareil entre en mode d'association rapide (Touch) lors de l'utilisation initiale. L'indicateur Wi-Fi clignote rapidement.

Dopo l'accensione, il dispositivo entrerà nella modalità di accoppiamento (Touch) durante il primo utilizzo. L'indicatore Wi-Fi lampeggia rapidamente.

После первого включения устройство перейдет в режим быстрого сопряжения. Индикатор Wi-Fi быстро мигает.

Após ligar, o dispositivo entrará em modo de pareamento rápido (Touch) durante o primeiro uso, então o indicador Wi-Fi piscará rapidamente.

三分钟内没有进行配网，设备将退出快速配网模式(Touch)。如需再次进入，长按配置按钮5秒直到Wi-Fi指示灯呈“快闪状态”即可。

It will exit the quick pairing mode (Touch) if the device is not paired within 3mins. If you want to enter this mode again, long press the configuration button for 5s until the Wi-Fi indicator flashes quickly and release.

Es wird den Schnellkopplungsmodus (Touch) verlassen, wenn das Gerät nicht innerhalb von 3 Minuten gekoppelt wird. Wenn Sie diesen Modus erneut aufrufen möchten, drücken Sie die Konfigurationstaste 5 Sekunden lang, bis die Wi-Fi-Anzeige schnell blinkt und loslassen.

3

Saldrá del modo de emparejamiento rápido (Touch) si el dispositivo no se conecta dentro de los 3 minutos. Si usted quiere volver a este modo, presione de manera sostenida el botón de configuración durante 5 segundos hasta que el indicador de Wi-Fi parpadee rápidamente y suelte.

Il quitte le mode d'appairage rapide (Touch) si l'appareil n'est pas appairé dans les 3 minutes. Si vous souhaitez accéder à nouveau à ce mode, appuyez longuement sur le bouton de configuration pendant 5 secondes jusqu'à ce que le voyant Wi-Fi clignote rapidement, puis relâchez-le.

Se il dispositivo non è accoppiato entro 3 minuti la luce uscirà dalla modalità di accoppiamento rapido (Touch). Se si desidera accedere nuovamente a questa modalità, premere e mantenere premuto per 5 secondi il pulsante di configurazione fino a quando l'indicatore Wi-Fi lampeggia rapidamente, quindi rilasciarlo.

Если устройство не выполнило связывание в течение 3 минут, оно выходит из режима быстрого связывания устройства (Touch). войдите в этот режим снова, нажмите и удерживайте кнопку конфигурации в течение 5 с, пока индикатор Wi-Fi не начнет быстро мигать, и затем отпустите.

O dispositivo sairá do modo de pareamento rápido (Touch) se não for pareado em até 3 minutos. Se quiser entrar no modo de pareamento novamente, pressione o botão de configuração por 5 segundos até o indicador piscar rapidamente e solte.

4

3

添加设备
Add the device
Gerät hinzufügen
Añadir el dispositivo
Ajouter l'appareil
Aggiungere il dispositivo
Добавить устройство
Adicione o aparelho

Scan QR code

点击“+”，选择“扫码添加”，再扫描包装内卡片上的二维码，直接添加。

Tap "+" and select "Scan QR code", then scan the QR code on the card in the package to add the device.

Tippen Sie auf „+" und wählen Sie „QR-Code scannen", dann scannen Sie den QR-Code auf der Karte in der Verpackung, um das Gerät hinzuzufügen.

5

LIKE IT!

Glad to know you are satisfied with SONOFF products.
It would mean a lot to us if you can take a minute to share your buying experience.

Share it on Amazon

Share it with your friends and family

Share it on your social media

Get the latest news by following us:

New arrival
Promotion
How-to videos

HAVE A PROBLEM?

We are so sorry for the inconvenience caused by the product.
Please contact us for help via the email address below.

support@itead.cc

We will get back to you as soon as possible.

YouTube

facebook

Presione "+" y seleccione "escanear código QR", luego escanee el código QR en la tarjeta en el paquete para agregar el dispositivo.

Tapez sur « + » et sélectionnez « Scanner le code QR », puis scannez le code QR sur la carte dans l'emballage pour ajouter le périphérique.

Toccare "+" e selezionare "Scansione codice QR", quindi effettuare la scansione del codice QR, sulla scheda presente nella confezione, per inserire il dispositivo.

Нажмите «+» и выберите «Сканировать QR-код», затем отсканируйте QR-код на карте в упаковке для добавления устройства.

Toque em "+", selecione "Digitalizar código QR" e digitalize o código QR no cartão na embalagem para adicionar o dispositivo.

6

User Manual

https://www.sonoff.tech/usermanuals

扫码或输入网址查看产品详细的说明书和帮助。

Scan the QR code or visit the website to learn about the detailed user manual and help.

Scannen Sie den QR-Code oder besuchen Sie die Website um auf die detaillierte Bedienungsanleitung zuzugreifen und hilfe.

Escanee el código QR o visite el sitio web para consultar la guía del usuario detallada y ayuda.

Scannez le code QR ou visitez le site web pour consulter le guide détaillé et aide.

Scansionare il codice QR o visita il sito web per consultare la guida utente dettagliata e aiuto.

Сканируйте этот QR-код или перейдите на наш веб-сайт для просмотра подробного руководство пользователя и помощи.

Scaneie o código QR ou visite o nosso website para consultar detalhadamente o guia do usuário e ajuda.

7

扫码阅读使用天猫精灵、Echo、Google语音控制教程。

Scan the QR code to read the voice control instruction for Amazon Echo and Google Home.

Scannen Sie den QR-Code, um die Anweisungen für die Sprachsteuerung für Amazon Echo und Google Home zu lesen.

Escanee el código QR para leer las instrucciones del control por voz de Amazon Echo y Google Home.

Scannez le code QR pour lire les instructions de contrôle vocal de l'Amazon Echo et Google Home.

Scansionare il codice QR per leggere le istruzioni di controllo vocale per Amazon Echo e Google Home.

Сканируйте этот QR для просмотра инструкций по голосовому управлению для Amazon Echo и Google Home.

Scaneie o código QR para ler as instruções para controle de voz Amazon Echo e Google Home.

8

FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could avoidthe user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunctionwith any other antenna or transmitter.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protectionagainst harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

9

the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Hereby, Shenzhen Sonoff Technologies Co., Ltd. declares that the radio equipment type Micro is in compliance with Directive 2014/53/EU.The full text of the EU declaration of conformity is available at the following internet address:

https://www.sonoff.tech/usermanuals

TX Frequency:
WiFi: 2412-2472MHz/2422-2462MHz

RX Frequency:
WiFi: 2412-2472MHz/2422-2462MHz

Output Power:
11.49dBm(802.11b), 10.61dBm(802.11g), 11.09dBm(802.11n20), 11.44dBm(802.11n40)

10

SONOFF

Shenzhen Sonoff Technologies Co., Ltd.
1001, BLDG8, Lianhua Industrial Park, shenzhen, GD, China
ZIP code: 518000 Website: sonoff.tech

MADE IN CHINA